

CORSPIC166X180
CORSPIC190X220




Assembly Instructions

Corsica Wave Aluminium Picnic Table








Before assembly please check you have all parts listed below.

PLEASE NOTE: We've tried to make this table as easy to assemble as possible.

In the unlikely event you have problems putting it together or missing pieces, please contact us.





PARTS LIST



A table top  x 1	B bench seat  x 2	C legs  x 4	D (m6x20 screw)  x 32 + 3	F  x 32
			E  x 32	G allen key  x 1

****PROTECT YOUR TABLE DURING ASSEMBLY****
To protect your table top from scratches during assembly, please assemble on the cardboard box.

Step 1: Attach table top



Step 2: Attach bench seats



Thank you for your purchase. Corsica tables are exclusively supplied by Chairforce.
To learn more about our products please visit www.chairforce.com.au and www.chairforce.co.nz

AU: Call: 08 9436 8570 Email: customer@brayco.com.au

NZ: Call: 09 271 5000 Email: sales@chairforce.co.nz



Please recycle
these instructions